AIR TECHNIQUES INCORPORATED

70 CANTIAGUE ROCK ROAD · P. O. BOX 870 · HICKSVILLE, NEW YORK 11802
TELEPHONE · 516 / 433-7676 TELEX: 64-0448

INSTALLATION INSTRUCTIONS FOR DAYLIGHT LOADER P/N 90090, 90095 AND FILM DUPLICATOR/DAYLIGHT LOADER P/N 92000

Read all instructions carefully before proceeding.

The four Phillips head screws required for Daylight Loader and Film Duplicator/Daylight Loader Installation are supplied in a plastic bag.

1. Remove the cover from the Peri-Pro Film Processor and turn it upside down.

2. Look for the four blind holes in the corners of the raised area on the inlet end of the cover. These four blind holes must be opened in order to mount the Daylight Loader. Place the tip of a 2/16 diameter (size no. 1) Phillips screwdriver into the blind hole. Using a small hammer, lightly strike the handle of the screwdriver to punch the hole open.

3. Turn the cover rightside up with the film inlet slot on your left. Check if the holes are fully opened and clean out if required. There may be chipping around the holes - this is normal and will not be visible after the Daylight Loader is mounted. Place the Daylight Loader on top of the cover with the view glass handle facing you.

4. Turn both the Daylight Loader and the cover upside down, holding both carefully. The holes in the Daylight Loader will now be visible through the punched out holes in the cover. Drive the mounting screws into these holes. Be careful not to put undue pressure on the view glass handle. Do not tighten any of the screws until all four screws have been inserted. Then tighten one at a time.
   Caution: Threads may be stripped by overtightening.

5. Turn the cover and the Daylight Loader assembly back to working position and place over the film processor.

6. Peel protective paper off view glass.

7. When installing a Film Duplicator/Daylight Loader (P/N 92000) plug the line cord into a grounded wall outlet.

8. The installation of the Daylight Loader to the Film Processor is now complete.